



Re-Order	Description	Size	Units
914756	Optional Nylon Outer Cover for Crash Pad™	3' x 4'	Each
914758	Optional Nylon Outer Cover for Crash Pad™	5' x 5'	Each
914757	Optional Cozy Cloth Outer Cover for Crash Pad™	3' x 4'	Each
914759	Optional Cozy Cloth Outer Cover for Crash Pad™	5' x 5'	Each

Purpose

The Crash Pad™ is filled with foam and contained by an outer nylon cover. Although this cover can be wiped clean if one wants to launder the cover, it is too time consuming to remove and replace the foam. For this reason, an optional outer cover is available that fits over the inner cover which is now available in two fabrics. This cover can be easily removed and laundered.

In order to minimize the “bounce effect” due to trapped air, vent holes are placed on the inner and outer cover.

Easy to Use

When the outer cover is placed over the inner cover it is critical that the vent holes are aligned to allow for the air to escape quickly. For this reason, a red strip of webbing is placed on both covers and when placing the 2nd cover on, assure that the red webbing is aligned in the same direction as the inner cover (Nylon Outer Cover Only).

Easy Care

Both covers can be cleaned with a germicidal cleaning solution or soap and water. The outer cover can be laundered at temperatures below 180° F (82° C). Dry at the low setting. Do not use bleach directly on the fabric.